

# KOHLER CONTACTS

## Kohler Europe / Jacob Delafon France

3, rue de Brennus  
93631 La Plaine Saint Denis Cedex  
Tel.+33 (0) 1 49 17 37 37

## Kohler UK

Cromwell Road  
Cheltenham  
Gloucestershire GL52 5EP  
Tel.+44 (0) 870 850 5551

## Kohler Deutschland

Holtgarde 30  
45739 Oer-Erkenschwick  
Tel.+49 (0) 2368 91 87 0

## Kohler Italia

Cassina Plaza, Edificio B, Scala 2  
Via Roma, 108  
20060 Cassina de' Pecchi (Mi)  
Tel.+39 (0)2 94437100

## Kohler Middle East

Al Thuraya Tower II, 9th Floor, Office 905  
P.O. Box 500431  
DIC, Dubai, UAE  
Tel.+971-4-3624650

## Колер Рус

Новокузнецкая ул., стр. 1, оф. 308  
115184 Москва, Россия  
Тел. +7 495 783 5223

## Kohler / Jacob Delafon Espana

Ctra. De Logrono km.17  
50629 Sobradiel  
Zaragoza  
Tel.+34 902 46 46 86

## Kohler / Jacob Delafon Maroc

207 Bd Anfa & rue Beaumarchais  
Casablanca  
Tel.+212 2 295 9740

## Australia Kohler Co.

Free Ph: 1 300 362 284  
Free Fax: 1 300 652 284  
[www.au.kohler.com](http://www.au.kohler.com)

## New Zealand Kohler NZ LTD

Free Ph: 0800 564 537 (0800 KOHLER)  
Free Fax: 0800 664 488  
[www.kohler.co.nz](http://www.kohler.co.nz)



# KOHLER®

ODEON UP / REACH 120cm E4730 / 18570W  
ODEON UP / REACH 105cm E4731 / 18571W  
ODEON UP / REACH 70cm E4732 / 18572W

ODEON UP / REACH 65cm GAUCHE / LEFT E4757G / 4946CK/E4757C  
ODEON UP / REACH 65cm DROITE / RIGHT E4758G / 4947CK/E4758C  
ODEON UP / REACH 80cm E4796 / 4796K  
ODEON UP / REACH DISABLE 74cm E4494 / 4156K

## Kohler Rus

Novokuznetskaya St., 7/11, bldg. 1, office 308  
115184 Moscow, Russia  
Tel.+7 495 783 5223

1

	A	B	C	D	E
ODEON UP / REACH 120	870	545	625	800	0
ODEON UP / REACH 105	770	545	625	800	0
ODEON UP / REACH 70	280	545	625	810	0
ODEON UP / REACH 65 GAUCHE / LEFT	280	575	655	790	-100
ODEON UP / REACH 65 DROITE / RIGHT	280	575	655	790	+100
ODEON UP / REACH 80	280	545	625	810	0
ODEON UP / REACH DISABLE 74	280	545	625	810	0

2

2 mm

- 18570W / E4730
- 18571W / E4731
- 18572W / E4732
- 4946K / E4757
- 4947K / E4758
- 4796K / E4796

3

5527-NF

1

	A	B	C	D	E
ODEON UP / REACH 120	870	545	625	800	0
ODEON UP / REACH 105	770	545	625	800	0
ODEON UP / REACH 70	280	545	625	810	0
ODEON UP / REACH 65 GAUCHE / LEFT	280	575	655	790	-100
ODEON UP / REACH 65 DROITE / RIGHT	280	575	655	790	+100
ODEON UP / REACH 80	280	545	625	810	0
ODEON UP / REACH DISABLE 74	280	545	625	810	0

2

12

- 18570W / E4730
- 18571W / E4731
- 18572W / E4732
- 4946K / E4757
- 4947K / E4758
- 4796K / E4796

3

5527-NF

4

5

4

5

6

7

6

7

8

Достоверную информацию уточняйте на [santehnica.ru](http://santehnica.ru).